

03C PONTOON RAIL KIT

Thank you for purchasing our product!

Please read these instructions and follow them step by step.

Step 1. Set the bottom brackets (REF. # 1) over the cross bars of the lifts bed. Set to desired width using 3/8" X 3" bolts, washers and nuts (REF. # 5, 6 & 7). Locate the top rail brackets (REF. # 2). With the tube to the inside of the lift, set the top rail brackets into the upright tube of the bottom brackets.

Step 2. Find the two pontoon rails (REF. # 3) with the 45 degree cut to the rear to the lift bolt to the side of the top rail bracket using 3/8" X 2 1/2" carriage bolt (REF. # 8). Bolt the 2 X 4 skid board (REF. # 4) to the top of the rail bracket using 3/8" X 3" carriage bolts.

Step 3. Set rail to desired height using 1/2" X 1" setscrews (REF. # 9) in the bottom brackets.

REF. #	PART #	DESCRIPTION	QTY
1	11C	BOTTOM BRACKET	4
2	12C	TOP RAIL BRACKET	4
3	50200	RAIL	2
4	50201	SKID BOARD	4
5	5084	3/8" X 3" BOLT	8
6	5070	3/8" WASHER	32
7	5056	3/8" NUT	24
8	5195	3/8" X 2 1/2" CARRIAGE BOLT	16
9	5174	1/2" X 1" SET SCREW	8

