

C18 43" HORIZONTAL BUMPER

Thank you for purchasing our product!

Please read these instructions and follow them step by step.

Place the horizontal bumper bracket (**REF. # 1**) over the bottom tube of the dock. Place horizontal bumper (**REF. # 2**) against tube and bracket and fasten with 3/8" X 2 1/2" bolts and washers (**REF. # 3 & 4**)

<u>REF. #</u>	<u>PART #</u>	<u>DESCRIPTION</u>	<u>QTY</u>
1	C39	HORI. BUMPER BRKT.	2
2	C17	HORI. BUMPER	1
3	5084	3/8" X 3" BOLT	2
4	5070	3/8" WASHER	2

