

C21 43" VERTICAL BUMPER

Thank you for purchasing our product!
Please read these instructions and follow them step by step.

Set the vertical bumper (**REF. # 1**) to the side or ends of your dock. Place the rear backer angle (**REF. # 2**) on the inside of the dock, with the notch end up and away from the top tube of the dock. Fasten to the bumper using 3/8" X 3" bolts and washers (**REF. # 3 & 4**).

<u>REF. #</u>	<u>PART #</u>	<u>DESCRIPTION</u>	<u>QTY</u>
1	C22	VERTICAL BUMPER 43"	1
2	30092	REAR BACKER ANGLE	1
3	5084	3/8" X 3" BOLT	2
4	5070	3/8" WASHER	2

