

**L91 SHORE END WHEEL KIT WITHOUT WHEELS**

**Thank you for purchasing our product!**

**\*Please read these instructions and follow them step by step.\***

<b>REF. #</b>	<b>PART #</b>	<b>DESCRIPTION</b>	<b>QUANTITY</b>
1	L57	SHORE END WH KIT ANGLE BRK	2
2	3107	HUB ASSEMBLY	2
3	5152	1/4" X 1 1/2" BOLT	2
4	5057	7/16" NUT	10
5	5058	1/2" NUT	4
6	5109	7/16" X 1" BOLT	10
7	5123	1/2" X 1" BOLT	4
8	5041	1/4" ACORN NUT	2
9	5069	7/16" WASHER	10

