

T92 DOCK HINGE KIT

Thank you for purchasing our product!
Please read these instructions and follow them step by step.

Line up the bolt holes on the hinge plate (**REF. # 4**) with the hole in the dock corner angle.
Attach using 1/2" X 1 1/2" bolts, 1/2" washers, and 1/2" nut (**REF. #. 1, 3, & 2**). Do not tighten
at this time. Place washer (**REF. # 3**) on bolt and insert through top hole of plate and dock.
Secure with washer and nylock nut (**REF. # 3 & 5**).

Tighten bolts on non-swivel side. Hinge kit is now ready to use.

<u>REF. #</u>	<u>PART #</u>	<u>DESCRIPTION</u>	<u>QTY</u>
1	5124	1/2" X 1 1/2" BOLT	6
2	5058	1/2" NUT	4
3	5071	1/2" WASHER	12
4	10005	HINGE PLATE	2
5	5039	1/2" NYLOCK NUT	2

